











Installation Guide RBC43



Customer support and warranty information is available at the APC Web site, www.apc.com.